

ROTOR MINI

last update 07/07/2015


BEL1104

Rotor Mini : code 923.EC._ _

max.50W QPAR16/GU-GZ10 or LED solution - 230V~ - CE - IP20 -  -  - 


BEL LIGHTING


BEL LIGHTING sprl
Avenue Ernest Solvay 42
B-1480 Saintes (Tubize)
Belgium
Phone: +32(0)2 3552428
Fax: +32(0)2 3550396
e-mail: info@bel-lighting.com
www.bel-lighting.com



INSTALLATION INSTRUCTIONS - PART A



1. FIT THE CEILING FIXATION ON THE CEILING
2. MAKE THE ELECTRICAL CONNECTION
3. PLACE THE LUMINARY
4. SWITCH ON

1 DIMENSIONS HOLES




2 ELECTRICAL CONNECTION


NL - Voeg de voedingskabel in de beschermingskoker (A)
FR - Insérer le câble d'alimentation dans la gaine de protection(A).
EN - Insert the feeder in the protection sheath (A)
DE - Das Kabel in die Schutzhülle einfügen (A)
ΕΛ - Παρεμβάλετε τον τροφοδοτή στη θηκιά προστασίας(A)



3



ACCESSORY SET (B)



PART

A

Lees de algemene gebruiksvoorwaarden : PART B
Lire attentivement les conditions générales d'utilisation: PART B
Read attentively the general instructions: PART B
Lesen Sie die allgemeinen Gebrauchsanweisungen: PART B
Διαβάστε της γενικές οδηγίες : PART B

WAARSCHUWING
AVERTISSEMENT
WARNING
WARNUNG
ΠΡΟΣΟΧΗ